



USER GUIDE

Solar Inverter

WVLVS-IP54-8KW

Solar Inverter



Contents

| | |
|--|-----------|
| ABOUT THIS MANUAL | 01 |
| Purpose | 01 |
| Scope | 01 |
| Safety instructions | 01 |
| WARNING MARKS | 02 |
| INTRODUCTION | 03 |
| Features | 03 |
| Basic system architecture | 03 |
| PRODUCT OVERVIEW | 04 |
| SPECIFICATIONS | 06 |
| INSTALLATION | 09 |
| Safety guidance | 09 |
| Unpacking and inspection | 09 |
| Preparation | 10 |
| Mounting the unit | 10 |
| Battery connection | 11 |
| AC input/output connection | 12 |
| PV connection | 14 |
| Final assembly | 15 |
| DRY and CT Contact Signal | 15 |
| Meter Communication | 15 |
| Wiring System for Inverter | 16 |
| Wiring System for dual output | 17 |
| OPERATION | 18 |
| Power on/off | 18 |
| Operation and display panel | 18 |
| LCD display icons | 19 |
| LCD operation flow chart | 21 |
| Base information page | 21 |
| Setting page | 24 |
| Energy stored data page | 31 |
| BMS information page | 31 |
| Rated information page | 32 |
| Lithium battery communication | 33 |
| PARALLEL INSTALLATION GUIDE | 34 |
| Introduction | 34 |
| Mounting the unit | 34 |
| Package contents | 35 |
| Wiring connection | 35 |
| LCD setting and display | 40 |
| Commissioning | 40 |
| WARNING CODE TABLE | 42 |
| FAULT CODE TABLE | 42 |

ABOUT THIS MANUAL

Purpose

This manual describes the assembly, installation, operation, warning code and fault code of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.









Safety Instructions

 **WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.**

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION** To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION** Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
10. Fuse is provided as over-current protection for the battery supply.
11. **GROUNDING INSTRUCTIONS** This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. **NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **WARNING!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.
14. **WARNING!!** This series of off-grid inverters provides a backfeed function without grid-tie protection. If enabled, implement protective measures prior to operation. The customer assumes full liability for any accidents resulting from the use of this function.

WARNING MARKS

Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

| Mark | Name | Instruction | Abbreviation | |
|---|---------|-------------------------|--|---|
|  | Danger | Danger | Serious physical injury or even death may occur if not follow relevant requirements. |  |
|  | Warning | Warning | Physical injury or damage to the device may occur if not follow relevant requirements. |  |
|  | Forbid | Electrostatic sensitive | Damage may occur if relevant requirements are not followed. |  |
|  | Hot | High temperature | Do not touch the base of the inverter as it will become hot. |  |
| | Note | Note | The procedures taken for ensuring proper operation. | Note |

INTRODUCTION

This is a multi-function inverter/charger, combining functions of inverter, MPPT solar charger and battery charger to offer uninterruptible power support with portable size. It's comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

Features

- Pure sine wave inverter
- Built-in MPPT solar charge controller
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- Auto restart while AC is recovering
- Overload/Over temperature/short circuit protection
- Inverter running without battery
- Lithium battery activation function
- Cold start function
- Parallel: Up to 9 units for single phase system; Up to 12 units for three-phase system, with maximum 9 units per phase. (Battery must be connected)
- Intelligent fan control greatly reduces fan noise
- Dual output load function


Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator or Utility
- PV modules (option)
- Meter/CT (option)



Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.



NOTE: The inverter must be connected to CT or meter to enable anti-reflux function. Otherwise, the feed power cannot be controlled. (Only CT with a ratio of 1:1000 is supported)


PRODUCT OVERVIEW



- | | |
|--------------------------------------|------------------------------------|
| 1. LCD display | 10. PV input connection port |
| 2. Charging indicator | 11. AC output port |
| 3. Fault or warning indicator | 12. AC input port |
| 4. Utility bypass/Inverter indicator | 13. Communication connection port* |
| 5. ESC button | 14. DRY and CT contact* |
| 6. UP button | 15. Battery+ connection port |
| 7. Down button | 16. Battery- connection port |
| 8. Enter button | 17. Ground wire port* |
| 9. Switch | |

13 Definition of BMS communication port pin

METER BMS-485




RS232 BMS-CAN

| NO. | BMS-485 | BMS-CAN | RS-232 | METER |
|-----|---------|---------|-----------|---------|
| 1 | RS485-B | NC | RS232-TXD | RS485-B |
| 2 | RS485-A | NC | RS232-RXD | RS485-A |
| 3 | VSS | VSS | VDD | VSS |
| 4 | NC | CAN.H | VSS | NC |
| 5 | NC | CAN.L | NC | NC |
| 6 | VSS | VSS | NC | VSS |
| 7 | RS485-A | NC | NC | RS485-A |
| 8 | RS485-B | NC | VSS | RS485-B |



14 NOTE: The inverter must be connected to CT or meter to enable Anti-backflow function. Otherwise, the feed power cannot be controlled. (Only CT with a ratio of 1:1000 is supported)



17 The earth terminal shall be connected. Select the 32 options in compliance with applicable local regulations.



SPECIFICATIONS

| Line mode specifications | |
|---------------------------------|---|
| Model | WVLVS-IP54-8KW |
| Rated output power | 8000VA |
| | 8000W |
| Nominal DC input voltage | 48V |
| Input voltage waveform | Sinusoidal (utility or generator) |
| Nominal input voltage | 230Vac |
| Low line voltage disconnect | 90Vac±3V(For Home Appliances)170Vac±3V(For Computers) |
| Low loss voltage re-connect | 100Vac±3V(For Home Appliances)180Vac±3V(For Computers) |
| High line voltage disconnect | 280Vac±3V |
| High line voltage re-connect | 270Vac±3V |
| Max AC input voltage | 280Vac±3V |
| Nominal input frequency | 50Hz/60Hz(Auto detection) |
| Low line frequency disconnect | 40±1Hz |
| Low line frequency re-connect | 42±1Hz |
| High line frequency disconnect | 65±1Hz |
| High line frequency re-connect | 63±1Hz |
| Output voltage waveform | As same as input waveform |
| Output short circuit protection | Line mode: Circuit Breaker; Battery mode: Electronic Circuits |
| Efficiency (Line mode) | >95%(Rated R load, battery full charged) |
| Transfer time (Single unit) | 10ms typical (UPS); 20ms typical (Appliances) |
| Transfer time (Parallel) | 50ms typical |
| Pass through without battery | Yes |
| Max. Bypass overload current | 50A |
| Max. Bypass input current | 65A |
| Max. Inverter/Rectifier current | 36.4A/8000W |









| Utility charge mode specifications | | | |
|-------------------------------------|--|-----------------------|-------|
| Model | WVLVS-IP54-8KW | | |
| Nominal input voltage | 230Vac | | |
| Input voltage range | 90-280Vac | | |
| Nominal output voltage | Dependent on battery type | | |
| Max. Grid charge current | 160A | | |
| Charge current regulation | 5A-160A(Adjustable unit is 1A) | | |
| Over charge protection | Yes | | |
| Grid charging current (I.max/I.min) |  <p>Relationship between battery charging current and grid voltage.</p> <p>160A/40A</p> | | |
| Solar charging & Grid charging | | | |
| Max. PV Open Circuit Voltage | 500V | | |
| PV voltage range | 85V-450V | | |
| Max. Input power | 16000W | | |
| Max. Solar charging current | 160A | | |
| Max. Charging current(PV+Grid) | 160A | | |
| Max. Input current | 27A+27A (ISC32A+32A) | | |
| Min. Startup voltage | 75V | | |
| Charge algorithm | | | |
| Algorithm | Three stage: Boost CC (Constant current stage)-> Boost CV(Constant voltage stage)-> Float FV(Constant voltage stage) | | |
| Charging curve |  | | |
| Battery type setting | Battery Type | Boost CC/CV | Float |
| | AGM | 56.4V | 54V |
| | Flooded | 58.4V | 54V |
| | Self-defined | Adjustable, up to 60V | |
| | Lithium | | |

| Inverter mode specifications | |
|---|---|
| Model | WVLVS-IP54-8KW |
| Rated output power | 8000VA |
| | 8000W |
| Nominal DC input voltage | 48V |
| Output voltage waveform | Pure sine wave |
| Nominal output voltage | 230Vac±5% |
| Nominal output frequency(Hz) | 50±0.3Hz/60±0.3Hz(Adjustable) |
| Parallel capability | Yes, single phase up to 9 units, three phase up to 12 units |
| Peak efficiency | 93% |
| Over-Load protection(SMPS load) | 5s@ ≥ 150%load; 10s@ 105%~150%load |
| Surge rating | 2* rated power for 5s |
| Capable of starting electric | Yes |
| Output short circuit protection | Yes |
| Cold start voltage | 46V |
| Low DC input shut-down Load < 50% @Load ≥ 50% | 43V |
| | 42V |
| High DC input alarm & fault | 62V±0.4V |
| High DC input recovery | 60V±0.4V |
| Battery voltage Limitation (V.bat0/V.bat1/V.bat2) |  |
| | 42V/50V/62V |
| Temperature limitation(Td) |  |
| | 45°C |
| When battery voltage is lower than "V.bat1", output power will be derated. The minimum AC output voltage is 180V. | |
| When ambient temperature is higher than 40°C/45°C, output power will be derated. The minimum AC output voltage is 180V. | |
| General specifications | |
| Operating temperature | -10C°~55C° |
| Range storage temperature | -15C°~60C° |
| Net weight(kg) | 17.50kg |
| Gross weight(kg) | 19.45kg |
| Product size(D*W*H) | 520x420x125mm |
| Package dimension(D*W*H) | 590x490x205mm |

INSTALLATION

Safety Guidance

Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

| | |
|--|--|
|  | <ul style="list-style-type: none"> After receiving this product, first confirm the product package is intact. If any question, contact the logistic company or local distributor immediately. The installation and operation of inverter must be carried out by professional technicians who have received professional trainings and thoroughly familiar with all the contents in this manual and the safety requirements of the electrical system. |
|  | <ul style="list-style-type: none"> Do not carry out connection/disconnection, unpacking inspection and unit replacement operations on the inverter when power source is applied. Before wiring and inspection, users must confirm the breakers on DC and AC side of inverter are disconnected and wait for at least 5 minutes. |
|  | <ul style="list-style-type: none"> Ensure there is no strong electromagnetic interference caused by other electronic or electrical devices around the installation site. Do not refit the inverter unless authorized. All the electrical installation must conform to local and national electrical standards. |
|  | <ul style="list-style-type: none"> Do not touch the housing of the inverter or the radiator to avoid scald as they may become hot during operation. |
|  | <ul style="list-style-type: none"> Ground with proper technics before operation. |
|  | <ul style="list-style-type: none"> Do not open the surface cover of the inverter unless authorized. The electronic components inside the inverter are electrostatic sensitive. Do take proper anti-electrostatic measures during authorized operation. |
|  | <ul style="list-style-type: none"> The inverter needs to be reliably grounded. |
|  | <ul style="list-style-type: none"> Ensure that DC and AC side circuit breakers have been disconnected and wait at least 5 minutes before wiring and checking. |

Unpacking and Inspection


Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:

| | | | | |
|--|---|--|---|--|
|  Inverter unit x 1 |  Manual x 1 |  WiFi module x 1 * |  Parallel communication cable x 1 |  Parallel communication terminal connector x 1 |
|  O-shaped terminal x 2 |  Expansion bolt x 3 |  Wall Hangers x 1 and Screws x 3 |  Battery input screw x 2 |  Case grounding screw x 1 |

* Note: WIFI module is optional.

Preparation


Before connecting all wirings, please take off bottom cover by removing four screws as shown below.



Mounting the Unit



Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface.
- Install this inverter at eye level in order to allow the LCD display to be read all the time.
- The ambient temperature should be between -10°C and 55°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the right diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.



! SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing three screws. It's recommended to use M4 screws.



Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size.

WARNING! All wiring must be performed by a qualified personnel.


WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.

| Model | Gauge | Cable(mm ²) | Torque Value |
|-------|--------|-------------------------|--------------|
| 8KVA | 1*1AWG | 50 | 2 Nm |

Please follow below steps to implement battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.
2. Connect all battery packs as units requires. It's suggested to connect at least 200Ah capacity battery.
3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 2 Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.

Connect the positive and negative battery wires to the following positions and tighten the nuts



WARNING: Shock hazard

Installation must be performed with care due to high battery voltage in series.



CAUTION!! Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.

CAUTION!! Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.

CAUTION!! Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

AC Input/Output Connection

CAUTION!! Before connecting to AC input power source, please install a separate AC breaker, a self resetting overvoltage and undervoltage protector and a SPD (Surge Protection Device) between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 65A for 8KVA.

CAUTION!! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.
WARNING! All wiring must be performed by qualified personnel.
WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires:


| Model | Gauge | Cable (mm ²) | Torque value |
|-------|-------|--------------------------|--------------|
| 8KVA | 6AWG | 13 | 1.4~1.6 Nm |

Recommended circuit breaker type for AC input:


| Models | Maximum bypass | Recommended circuit breaker |
|--------|----------------|-----------------------------|
| 8KVA | 65A | 2P-65A |

Please follow below steps to implement AC input/output connection:

1. Before making AC input/output connection, be sure to open DC protector or disconnecter firstly.
2. Remove insulation sleeve 10mm for three conductors. And shorten phase L and neutral conductor N by 3mm.




3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⊕) firstly.



WARNING:
 Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws. Be sure to connect PE protective conductor (⊕) firstly.



5. Make sure the wires are securely connected.

CAUTION: Important
 Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trigger overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

PV Connection



CAUTION: Before connecting to PV modules, please install separately a DC circuit breaker and a SPD (surge Protection Device) between inverter and PV modules.

WARNING! All wiring must be performed by qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

| Model | Cable Size | Cable (mm ²) | Torque |
|-------|------------|--------------------------|--------|
| 8KVA | 8 AWG | 8 | 1.2Nm |

PV module selection:


When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
2. Max. power voltage (Vmp) should be during PV array MPPT voltage range.


| Solar charging mode | |
|------------------------------------|--------------|
| Inverter model | 8KVA |
| Max. PV array open circuit voltage | 500V |
| PV array mppt voltage range | 85Vdc~450Vdc |

Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10mm for positive and negative conductors.




2. Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.



3. Make sure the wires are securely connected.

Final Assembly


After connecting all wirings, please put bottom cover back by screwing four screws as shown below.



DRY and CT Contact Signal (the CT is optional)

| Unit status | Condition | Dry contact port: | | | |
|-------------|--|-------------------|--|--------|--|
| | | | | | |
| | | NO & C | | NC & C | |
| Power off | Unit is off and no output is powered. | Open | | Close | |
| Power on | Battery voltage < Setting value in Program 06 | Close | | Open | |
| | Battery voltage > Setting value in Program 07 or battery charging reaches floating stage | Open | | Close | |


Meter Communication (the meter is optional)




*CT connection method (the CT is optional): Connect the white wire to CT+ and the black wire to CT-.

- NOTE:**
1. The inverter must be connected to CT or meter to enable anti-reflux function. Otherwise, the feed power cannot be controlled. (Only CT with a ratio of 1:1000 is supported)
 2. Only one connection shall be selected: either the CT or the electricity meter. Both shall not be connected at the same time.

Wiring System for Inverter




Wiring System for dual output



NOTE: The dual output port "LOAD-2" for the unimportant appliances. It's function can be set by Setting Page in program 60 to 66.

OPERATION

Power ON/OFF



Once the unit has been properly installed and the batteries are connected well, simply press on/off switch (located on the bottom of the case) to turn on/off the unit.

Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.




| Function Key | Icon | Description |
|--------------|------|---|
| ESC | | To previous page |
| UP | | To go to previous selection |
| DOWN | | To go to next selection |
| ENTER | | To confirm the selection or go to next page |

| LED Indicator | Icon | Status | Description |
|---------------|---------------|----------|---|
| Battery | CHG | Solid 0n | Battery is fully charged. |
| | | Flashing | Battery is charging. |
| Grid/Inverter | INV AC | Flashing | Output is powered by Battery or PV in battery mode. |
| | | Solid 0n | Output is powered by grid in Line mode. |
| Fault | FAULT | Solid 0n | Fault occurs in the inverter. |
| | | Flashing | Warning condition occurs in the inverter. |

Buzzer Information

| | |
|-------------|---|
| Buzzer beep | Press any button, the buzzer will last for 0.1s. Hold on the "ENTER" button, the buzzer will last for 3s. If in fault event, the buzzer will keep going. If in warning event, the buzzer will beep discontinuous (Check more information on the chapter of "Warning Code Table"). |
|-------------|---|


LCD display Icons



| Icon | Function description |
|--|--|
| Input Source Information | |
| | Indicate input voltage, input frequency, PV voltage, PV power, battery voltage and charger current. |
| Configuration Program and Fault Information | |
| | Indicates the setting programs. |
| | Indicates the warning and fault codes. Warning: flashing with warning code. Fault: lighting with fault code. |

| Output Information | |
|---|--|
| OUTPUT BMS L1 Kwh L2 VA L3 % Hz 8.8.8 | Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current. |
| Battery Information | |
| | Indicates battery level by 0-24%,25-49%,50-74% and 75-100%. The battery is connected normally, this icon is always on. |
| | If the inverter is in the process of lithium battery activation, or the battery is not connected, or the inverter is not connected to the grid and the battery voltage is low, this icon will flash. |
| | Indicates Lithium battery type. |
| | BMS Indicates communication is built between inverter and BMS. Indicates BMS allows battery discharge. Indicates BMS allows battery charge. Force charge occurs if icon flash. |
| Mode Operation Information | |
| | Indicates load is supplied by utility directly. |
| | Indicates the utility charger circuit is working. |
| | Indicates the inverter/charger is working. |
| | Indicates PV MPPT is working to power load. |
| | Indicates PV MPPT is working to charge battery. |
| | Indicates battery is discharging to load. |
| Mute Operation | |
| | Indicates unit alarm is disabled. |
| | The meter indicates that it is on. |

LCD operation flow chart




On base information page, pressing and holding "ENTER" key for 3 sec, the unit will enter parameters page. Press "UP" or "DOWN" key to switch the selection and press "ENTER" key to enter selected page. Press "ESC" key to back to previous page.

Base information Page


1. The base information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:
2. By default, 1 and 2 are displayed, indicating output from both channels. If the second output is disconnected, only 1 is displayed. If item 64 is set to single output, neither 1 nor 2 is displayed.

| | |
|--|---|
| <p>Default interface Left: PV1 power. Right: Load power and dual output state (1, 2).</p> | <p>Left: PV1 power. Right: PV daily power generation. Middle: indicates that the current page displays PV information.</p> |
|--|---|


Left: PV1 voltage.
Right: PV1 input current.
Middle: \overline{PV} indicates that the current page displays PV information.




Left: PV2 power.
Right: PV daily power generation.
Middle: \overline{PV} indicates that the current page displays PV information.




Left: PV2 voltage.
Right: PV2 input current.
Middle: \overline{PV} indicates that the current page displays PV information.




Left: Grid power, use electricity is "+", feed to grid is "-".
Right: Grid daily consume power.
Middle: \overline{AC} Indicates that the current page displays grid information.




Left: Grid voltage.
Right: Grid power, use electricity is "+", feed to grid is "-".
Middle: \overline{AC} Indicates that the current page displays grid information.




Left: Grid frequency.
Right: Grid current.
Middle: \overline{AC} Indicates that the current page displays grid information.




Left: Battery power(charging is "+"; discharging is "-").
Right: Battery SOC(displaying the battery voltage when without BMS).
Middle: \overline{BA} Indicates that the current page displays battery information.




Left: Battery voltage.
Right: Battery charge-discharge current(charge-discharge to display by means of the energy direction).
Middle: \overline{BA} Indicates that the current page displays battery information.




Left: Output load power in VA.
Right: Output load power in Watt.
Middle: \overline{LD} Indicates that the current page displays output load information.



Left: Output frequency.
Right: Output voltage.
Middle: \overline{LD} Indicates that the current page displays output load information.




Left: Output current.
Right: Percentage of output power.
Middle: \overline{LD} Indicates that the current page displays output load information.



Date
2023-06-01



Time
10:30:25



Setting Page

Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit. Keep pressing UP or DOWN button after 1.5 seconds, it will increase or decrease setting value quickly.

Setting items

| | | Selectable option | | |
|----|--|---|-------------------|--|
| 00 | Exit setting | | ESC | |
| 01 | Battery type setting | Default | AGM | If "User-Defined" or "Lib" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 03, 04 and 05. If "Lib" is selected, inverter can charge lithium battery when the lithium battery need to be activated. Please make sure lithium battery is connected before you start up inverter. If inverter doesn't connect battery or lithium battery, do not select "Lib" battery type. |
| | | bAt | AGm | |
| | | Flooded | FLd | |
| | | bAt | FLd | |
| | | self-defined | USE | |
| | | Lib | LIb | |
| 02 | BMS type | Default | 1 | Default Protocol. (BMS-485) |
| | | bns | 0 | Protocol 0. (BMS-485) |
| | | BMS | 20 | Protocol 20. (BMS-CAN) |
| | | bns | 21 | Protocol 21. (BMS-CAN) |
| 03 | Bulk charging voltage setting (CV voltage) | Default | 48V model | If "self-defined" or "Lib" is selected in program 01, this program is enabled. Setting range is from 48.0V to 60.0V. |
| | | | 56.4 _v | |
| 04 | Floating charging voltage | Default | 48V model | If "self-defined" or "Lib" is selected in program 01, this program is enabled. Setting range is from 48.0V to 60.0V. |
| | | | 54.0 _v | |
| 05 | Low DC cut-off voltage or SOC | When only powered by battery, if the battery voltage /SOC is lower than the set value of program 05, the inverter will shut down. | | |
| | | Default | 48V model | If "self-defined" or "Lib" is selected in program 01, this program is enabled. Setting range is from 42.0V to 48.0V. |
| | | | 42.0 _v | |

| | | | | | | |
|----|--|---------|----------|---------------|--|--|
| | | Default | | 10 % | If the battery type is lithium battery, the set value will change to SOC. Setting range is from 0% to 90%. | |
| 06 | Setting battery voltage or SOC point back to utility when selecting "SBU priority" in program 24 | Default | | 48V model | 46.0 _v | Setting range is from 44.0V to 54.0V. Increment of each click is 0.1V. |
| | | Default | | 20 % | | If the battery type is lithium battery, the set value will change to SOC. Setting range is from 5% to 90%. |
| 07 | Setting battery voltage point back to battery mode when selecting "SBU priority" in program 24 | Default | | 48V model | 54.0 _v | Setting range is from 48.0V to 60.0V. Increment of each click is 0.1V. |
| | | | | Fully charged | FUL | Battery should be charged to float charging stage. |
| | | Default | | 70 % | | If the battery type is lithium battery, the set value will change to SOC. Setting range is from 10% to 100%. |
| 09 | Max charging current (Utility charge current +PV charging current) | Default | | 60A | 60 ^A | Setting range is from 5A to 160A. Increment of each click is 1A. |
| 10 | Max utility charging current setting | Default | | 60A | 60 ^A | Setting range is from 5A to 160A. Increment of each click is 1A. |
| 20 | AC output mode | Default | | Single | SIG | When the units are used in parallel with single phase, please select "PAL" in program 20. It's required to have at least three inverters to support three-phase equipment. It's required to have at least one inverter in each phase or it's up to ten inverters in one phase. Please select "3P1" in program 20 for the inverters connected to L1 phase, "3P2" in program 20 for the inverters connected to L2 phase and "3P3" in program 20 for the inverters connected to L3 phase. Before starting up inverters, please connect all N wires of AC output together. |
| | | | | Parallel | PAL | |
| | | | | L1 Phase | 3P1 | |
| | | | | L2 Phase | 3P2 | |
| | | | L3 Phase | 3P3 | | |

NOTE: The setting value of item "07" should be larger than the setting value of item "06".

| | | | |
|----|-----------------------------|---|---|
| 21 | Output voltage setting | Default OPV 21 230V | Output voltage configuration. |
| | | 220V OPV 21 220V | |
| | | 240V OPV 21 240V | |
| 22 | Output frequency setting | Default OPF 22 50Hz | Output frequency configuration. |
| | | 60Hz OPF 22 60Hz | |
| 23 | Utility input range setting | Default AC 23 APL | Mains operating range: APL: 90-280V; UPS: 170-280V. The APL mode is suitable for ordinary household electrical loads. UPS mode is suitable for computer loads. When the effect is not satisfactory, it is recommended to adjust to APL. |
| | | Appliance mode AC 23 UPS | |
| 24 | Output source priority | Default PV >> Utility >> Battery OPS 24 SUB | PV provides power to the loads first. If PV is not sufficient, utility will supply power the loads at the same time. Battery will provide power to loads only when utility is not available. |
| | | Utility >> PV >> Battery OPS 24 USB | Utility provides power to the loads first. PV and battery will provide power to loads only when utility is not available. |
| | | PV >> Battery >> Utility OPS 24 SBU | PV provides power to the loads first. If PV is not sufficient, battery will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to the setting point in program 6. |
| | | Intelligent output source priority OPS 24 INT | The intelligent priority can use more solar energy and save electricity bills. It is applicable to South Asia (such as Pakistan) and Africa. In this priority mode, the PV provides power to the loads first. If PV is not sufficient, battery or utility will supply power to the loads at the same time. If the energy storage system is not installed with solar panels, do not choose this priority mode. |

| | | | |
|----|-----------------------------------|--|---|
| 25 | Charger priority | If inverter is working in utility mode, charger priority can be set as below. However, when inverter is working in battery mode, only PV can charge battery. | |
| | | Default [HS 25 [50 | PV First PV will charge battery first. Utility will charge battery only when PV is unavailable. |
| | | [HS 25 SNU | PV and Utility PV and utility will charge battery together. |
| | | [HS 25 050 | PV Only Only PV can charge the battery. |
| 26 | Feeding power to grid | Default FPG 26 d1 S | Disable If selected, inverter is not allowed to feed exceeding solar power to grid. |
| | | FPG 26 ENA | Enable If selected, inverter is allowed to feed exceeding solar power to grid. |
| 27 | Overload bypass function | Default L6P 27 ENA | If it is enabled, the inverter will switch to utility mode if overload happens in battery mode. The value is valid in SBU /INT mode. |
| | | L6P 27 d1 S | |
| 28 | Overload restart function | Default OLT 28 ENA | If it is enabled, the inverter will auto restart when overload occurs. |
| | | OLT 28 d1 S | |
| 29 | Over temperature restart function | Default OLT 29 ENA | If it is enabled, the inverter will auto restart when over temperature occurs. |
| | | OLT 29 d1 S | |
| 30 | Power -Voltage curve | Default PU 30 ENA | It is used to adjust the inverter active power according to the grid voltage. When the grid voltage exceeds 250V, the inverter begins to reduce active power. |
| | | PU 30 d1 S | |

| | | | | | |
|----|---|---------|--|----------------|--|
| 31 | Zero Export Power | 2EP | | Default 0 | Regulate the input power of the Grid while in SBU Mode. Setting range is from -90W to 90W. Increment of each click is 10W. |
| 32 | PEN Relay | Default | | Disable DIS | Please select whether to enable this function based on local grid regulations: When set to DISABLE (default), the N wire port and the ground wire port are disconnected inside the inverter. When set to ENABLE, the N wire port and the ground wire port are connected inside the inverter. |
| | | | | Enable ENA | |
| 40 | Backlight of LCD | Default | | Enable ENA | If selected, LCD backlight will be always-on. |
| | | | | Disable DIS | If selected, LCD backlight will be off after no button is pressed for 60s. |
| 41 | Auto return to the first page of display screen | Default | | Disable DIS | If selected, the display screen will stay at latest screen user finally switches. |
| | | | | Enable ENA | If selected, it will automatically return to the first page of display screen (Input voltage / output voltage) after no button is pressed for 60s. |
| 42 | Buzzer alarm | Default | | Enable ENA | If selected, buzzer is allowed to beep. |
| | | | | Disable DIS | If selected, buzzer is not allowed to beep. |
| 44 | Reset default | Default | | Disable DIS | If selected, default initial settings page. |
| | | | | Enable ENA | If selected, Enable restores all settings other than the parallel. Output mode setting item (20) to their initial values. |
| 45 | Fan work mode | Default | | PFC | In performance mode, the inverter will perform at it's highest performance. |
| | | | | BLC | Balanced mode, applicable to the condition of 75% output power and 110A charge current limitation, to reduce additional noise greatly. |
| | | | | SLC | Silent mode, applicable to the condition of 50% output power and 80A charge current limitation, to reduce additional noise extremely. |

| | | | | | |
|----|---|---------|--|--------------------|--|
| 46 | Failure recovery | Default | | Disable DIS | If selected, when the inverter enter the fault state, the inverter will not exit the fault state or start up again. |
| | | | | Enable ENA | If selected, when the inverter enter the fault state, the inverter will exit the fault state and start up again. |
| 50 | Time setting-Year | Year | | 23 | Setting range is from 23 to 99. |
| 51 | Time setting-Month | Month | | 8 | Setting range is from 1 to 12. |
| 52 | Time setting-Day | Day | | 20 | Setting range is from 1 to 31. |
| 53 | Time setting-Hour | Hour | | 21 | Setting range is from 0 to 23. |
| 54 | Time setting-Minute | Minute | | 43 | Setting range is from 0 to 59. |
| 55 | Time setting-Second | Second | | 50 | Setting range is from 0 to 59. |
| 60 | Low DC cut off voltage on second output | Default | | 48V model 42.0V | Setting range is from 42.0V to 48.0V. Increment of each click is 0.1V. This low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected. |
| | | Default | | 10% | If any type of lithium battery is selected in program 1, this parameter value will be displayed in percentage and value setting is based on battery capacity percentage. Setting range is from 0% to 95%. Increment of each click is 1%. |
| 62 | Scheduled time for 2nd AC output on | Default | | 0 | Setting range is from 00:00 to 23:00. Increment of each click is 1 hour. Within scheduled on/off time setting in program 62 and 63, 2nd AC output will be turn on/off. |
| 63 | Scheduled time for 2nd AC output off | Default | | 0 | |

| | | | |
|----|----------------------------------|--|--|
| 64 | Dual output Settings | Default SPt 64 Enable RUT | 1. The second output is normally on: The grid is power on. 2. The second output is turned off: The grid is power off and the battery voltage or SOC is less than program 60. 3. The second output is recovery: The grid is power off and the battery voltage > program 07 setting voltage, or the SOC > program 07 setting SOC. NOTE: Only generator function is disable, the second output can be setting successfully. |
| | | SPt 64 1 n | 2nd AC output will be turn on/off according to setting in program 62 and 63. |
| | | SPt 64 Disable dis | Disabled, single output only. |
| 65 | Generator power limit | Default GNP 65 12 ^{kw} | Generator input power limit, set range from 1kW to 12kW, increase by 1kW per click. Note: 1. The set value must not exceed the generator's rated power to prevent device damage; 2. This function becomes ineffective when load power exceeds the set value (input power will match load demand); 3. The set value allocates power flexibly: e.g., if set higher than the load, surplus power will automatically charge the battery. 4. The maximum port current is 50A. |
| | | | |
| 66 | Generator function setting | Default GEN 66 Disable dis | If selected, Generator function is disable, the dual output function is enable according to the program 64. |
| | | For 8KVA model GEN 66 Enable ENR | If selected, Generator function is enable, the dual output function is disable in the program 64. |
| 67 | Scheduled time for AC charge on | Default ACO 67 0 | Setting range is from 0~23 hour. If the time achieves the setting vaule, AC charge will be allowed/not allowed. |
| 68 | Scheduled time for AC charge off | Default ACF 68 0 | If the setting time for AC charge on and off are the same, the AC charge will be allowed always. |
| 80 | Zero Export Mode | Default Lod 80 0 | If "Meter" is selectes, Meter Protocol can set up in program 81. NOTE: The inverter must be connected to CT or meter to enable anti-reflux function. Otherwise, the feed power cannot be controlled. (Only CT with a ratio of 1:1000 is supported) |
| | | CT [t 80 1 | |

| | | | |
|----|----------------|------------------------------|-------------------|
| | | Meter nnt 80 2 | |
| 81 | Meter Protocol | Default nnp 81 1 | Default Protocol. |
| | | Meter Protocol nnp 81 100 | Protocol 0. |

Energy stored data Page





The energy stored data will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

| | | |
|---|--|--|
| PV generated energy today 88 kWh DAY 88 ^{kWh} | PV generated energy this month 88 kWh MON 88 ^{kWh} | PV generated energy this year 89 kWh YEA 89 ^{kWh} |
| PV generated energy current in total 348 kWh TOT 348 ^{kWh} | Load consumed energy today 78 kWh DAY 78 ^{kWh} | Load consumed energy this month 78 kWh MON 78 ^{kWh} |
| Load consumed energy this year 80 kWh YEA 80 ^{kWh} | Load consumed energy in total 272 kWh TOT 272 ^{kWh} | |

BMS information Page




The BMS information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

| |
|---|
| Battery pack number / mean SOC Connected battery pack number is 4, mean SOC is 97% |
| [4 AL 97% |

| | |
|--|---|
| <p>BMS voltage /SOC BMS voltage is 54.0V, SOC is 99% on battery pack of address 1</p>  | <p>BMS voltage / current BMS voltage is 54.0V, current is 5A on battery pack of address 1</p>  |
| <p>BMS highest temperature / lowest temperature BMS highest temperature is 25°C, lowest temperature is 20°C on battery pack of address 1</p>  | <p>BMS fault code / flag BMS fault code is 0, flag is 000 on battery pack of address 1</p>  |

Rated information Page


The rated information will be switched by pressing "Up" or "DOWN" key. The selectable information is switched as below order:

| | |
|---|--|
| <p>Rated VA / WATT Rated VA is 8kVA, WATT is 8kW</p>  | <p>Rated battery voltage / Max. charge current Rated battery voltage is 48V, Max.charge current is 160A</p>  |
| <p>Firmware version Firmware version is 1400</p>  | |

Lithium Battery Communication

It's allowed to connect lithium battery and build communication only which it has been configured. Please follow bellow steps to configure communication between lithium battery and inverter.


1. Connect power cable between lithium battery and inverter. Please pay attention to the terminals of positive and negative. Make sure the positive terminal of battery is connected to the positive terminal of inverter, and the negative terminal of battery is connected to the negative terminal of inverter.
2. The communication cable is bundled with lithium battery. Both sides are RJ45 port. One port is connected to the BMS port of inverter and the other one is connected to the COMM port of lithium battery.




3. Configure battery type to "Lib" in LCD setting No.01.

The battery type is Lib

BAT 01 Lib



4. Power up lithium battery and inverter. Wait a moment, if the communication is built between them, LCD will show you "BMS" icon as below.



5. Roll LCD real time information pages by pressing "UP" or "DOWN" button, as below page, you can see the parameters of SOC in the communication system.



This page means SOC is 80%.

PARALLEL INSTALLATION GUIDE

Introduction

This inverter can be used in parallel with two different operation modes.


1. Parallel operation in single phase with up to 9 units, the supported maximum output power is 72kW/72kVA.
2. Mlaximum twelve units work together to support three-phase equipment. Nine units support one phase maximum. The supported maximum output power is 96kW/96kVA and one phase can be up to 72kW/72kVA.

NOTE 1: If this unit is bundled with share current cable and parallel cable, this inverter is default supported paralle operation. You may skip section 2.

NOTE 2: Under parallel operation modes, battery must be connected with inverters.

NOTE 3: Before starting up inverters, please connect all positive (+) and negative (-) wires of battery together.

Mounting the Unit



NOTE: For proper air circulation to dissipate heat, allow a clearance of approx 60cm to the side and approx 60cm above and below the unit. Be sure to install each unit in the same level.

Package Contents

In parallel kit, you will find the following items in the package:




Parallel communication cable x 1 pcs




Parallel communication terminal connector x1 pcs

Wiring Connection

Inverters Communication Connection




Connect parallel communication connector to the first one and the last one.



Connect parallel communication cable one by one.


Single Phase Parallel connection diagram for two inverters in parallel for WVLSV-IP54-8KW.



⚠ WARNING!! Strictly maintain insulation between PV ports in parallel systems. A single PV module's L/N lines **MUST NOT** be connected to PV ports of two or more inverters in the parallel configuration.

NOTE: Before starting up inverters, please connect all positive (+) and negative (-) wires of battery together.

Single Phase Parallel connection diagram for 3-6 inverters in parallel for WVLSV-IP54-8KW.




⚠ WARNING!! Strictly maintain insulation between PV ports in parallel systems. A single PV module's L/N lines **MUST NOT** be connected to PV ports of two or more inverters in the parallel configuration.

NOTE:

1. "n" is the number of parallel connections of the inverters.
2. Before starting up inverters, please connect all positive (+) and negative (-) wires of battery together.


Three Phase Parallel connection diagram for three inverters in parallel for WWLVS-IP54-8KW.



WARNING!! Strictly maintain insulation between PV ports in parallel systems. A single PV module's L/N lines **MUST NOT** be connected to PV ports of two or more inverters in the parallel configuration.

NOTE: Before starting up inverters, please connect all positive (+) and negative (-) wires of battery together.

Three Phase Parallel connection diagram for 4-12 inverters in parallel for WWLVS-IP54-8KW.








WARNING!! Strictly maintain insulation between PV ports in parallel systems. A single PV module's L/N lines **MUST NOT** be connected to PV ports of two or more inverters in the parallel configuration.

NOTE:

1. "n1" / "n2" / "n3" is the number of parallel units for P1/P2/P3 phase.
2. Before starting up inverters, please connect all positive (+) and negative (-) wires of battery together.
3. Each phase is connected with at least one, a maximum of 6 parallel units for same phase, and a maximum of 12 parallel units for three phases.

LCD Setting and Display

Setting Program

| | | | |
|----|----------------|---|--|
| 20 | AC output mode | Single  | When the units are used in parallel with single phase, please select "PAL" in program 20. It is required to have at least three inverters or maximum twelve inverters to support three-phase equipment. It's required to have at least one inverter in each phase or it's up to ten inverters in one phase. Please select "3P1" in program 20 for the inverters connected to L1 phase, "3P2" in program 20 for the inverters connected to L2 phase and "3P3" in program 20 for the inverters connected to L3 phase. Before starting up inverters, please connect all N wires of AC output together. |
| | | Parallel  | |
| | | L1 Phase  | |
| | | L2 Phase  | |
| | | L3 Phase  | |

Commissioning

Parallel in single phase



Step 1: Check the following requirements before commissioning:

- Correct wire connection.
- Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.

Step 2: Turn on each unit and set "PAL" in LCD setting program 20 of each unit. And then shut down all units.



NOTE: To be safe, it's better to turn off switch when setting LCD program.

Step 3: Turn on each unit.

| | |
|---|--|
| LCD display in Master unit  | LCD display in Slave unit  |
|---|--|

NOTE: Master and slave units are randomly defined.

Step 4: Switch on all AC breakers of Line wires in AC input. It's better to have all inverters connect to utility at the same time. However, these inverters will automatically restart. If detecting AC connection, they will work normally.

| | |
|---|--|
| LCD display in Master unit  | LCD display in Slave unit  |
|---|--|

Step 5: If there is no more fault alarm, the parallel system is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Support three-phase equipment




Step 1: Check the following requirements before commissioning:


- Correct wire connection.
- Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.




Step 2: Turn on all units and configure LCD program 20 as P1, P2 and P3 sequentially. And then shut down all units.

NOTE: To be safe, it's better to turn off switch when setting LCD program.

Step 3: Turn on all units sequentially.

| | | |
|---|---|---|
| LCD display in L1-phase unit  | LCD display in L2-phase unit  | LCD display in L3-phase unit  |
|---|---|---|

Step 4: Switch on all AC breakers of Line wires in AC input. If AC connection is detected and three phases are matched with unit setting, they will work normally. Otherwise, the AC icon  will flash and they will not work in line mode.

| | | |
|---|---|---|
| LCD display in L1-phase unit  | LCD display in L2-phase unit  | LCD display in L3-phase unit  |
|---|---|---|


Step 5: If there is no more fault alarm, the system to support 3-phase equipment is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

NOTE 1: To avoid overload occurring, before turning on breakers in load side, it's better to have whole system in operation first.


NOTE 2: Transfer time for this operation exists. Power interruption may happen to critical devices, which cannot bear transfer time.

WARNING CODE TABLE

When fault event happens, the fault LED is flashing. At the same time, warning code, icon  is shown on the LCD screen.

| Warning Code | Warning Information | Audible Alarm | Trouble shooting |
|--------------|--|-------------------------------|---|
| 01 | Overload | Beep twice every second | Reduce the loads. |
| 02 | Fan is locked (up) | Beep three times every second | Check if the Fans wiring connected well. Replace the fan. |
| 03 | Fan is locked (down) | Beep three times every second | Check if the Fans wiring connected well. Replace the fan. |
| 04 | Grid over voltage warning | No buzzer alarm | Check whether the grid voltage exceeds the allowable range of the inverter. |
| 05 | Output not connected together in parallel mode | No buzzer alarm | Check whether the output load of the inverter is normal, and check whether the inverters are connected together in the same phase. |
| 06 | Remote shutdown warning | No buzzer alarm | Check if remote shutdown is enabled via WIFI. Disable the enable or restart the inverter. |
| 07 | Second output overload | No buzzer alarm | Reduce the connected load by switching off some equipment, and restart the unit, if the error happens again, please return to repair center. |
| 08 | BMS communication failure | No buzzer alarm | Check whether the inverter 01 setting item is selected for LI battery. If item 01 is set to lithium battery mode, check whether the communication line between the battery pack and the inverter is properly connected. |
| 10 | Parallel grid lost | No buzzer alarm | Check whether the mains input cable of the inverter is abnormal, and restart the unit, if the error happens again, please return to repair center. |

FAULT CODE TABLE

When fault event happens, inverter will cut off output, and the fault LED is solid on. At the same time, fault code, icon  and **ERROR** are shown on the LCD screen.

| Fault Code | Fault information | Trouble Shooting |
|------------|--------------------------|---|
| 01 | Bus voltage is too high | AC Surge or internal components failed. Restart the unit, if the error happens again, please return to repair center. |
| 02 | Bus voltage is too low | Restart the unit, if the error happens again, please return to repair center. |
| 03 | Bus soft start fail | Internal components failed. Restart the unit, if the error happens again, please return to repair center. |
| 10 | Inverter soft start fail | Internal components failed. Restart the unit, if the error happens again, please return to repair center. |

| | | |
|----|---|--|
| 11 | Over current or surge detected by Software | Restart the unit, if the error happens again, please return to repair center. |
| 12 | Over current or surge detected by hardware | Restart the unit, if the error happens again, please return to repair center. |
| 13 | Output voltage is too low | Reduce the connected load. Restart the unit, if the error happens again, please return to repair center. |
| 14 | Output voltage is too high | Restart the unit, if the error happens again, please return to repair center. |
| 15 | Output short circuited | Check if wiring is connected well and remove abnormal load. |
| 16 | Inverter current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 17 | Current feedback into the inverter is detected. | 1. Restart the inverter. 2. Check if L/N cables are not connected reversely in all inverters. 3. For parallel system in single phase, make sure the sharing cables are connected in all inverters. For supporting three-phase system, make sure the sharing cables are connected in the inverters in the same phase, and disconnected in the inverters in different phases. 4. If the problem remains, please contact your installer. |
| 20 | Overload time out | Reduce the connected load by switching off some equipment. |
| 21 | OP current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 22 | Sharing current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 23 | The AC input and output wire sare inversely connected | 1. Please check AC input and output wires are connected correctly. 2. If this error happens during parallel installation, please check wires connection. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer. |
| 24 | The output relay exception | Restart the unit, if the error happens again, please return to repair center. |
| 30 | Battery voltage is too high | Check if spec and quantity of batteries are meet requirements. |
| 31 | Over current happen at DC/DC circuit | Restart the unit, if the error happens again, please return to repair center. |
| 32 | DC/DC current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 33 | No.2 DCDC current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 34 | DC/DC soft start fail | Restart the unit, if the error happens again, please return to repair center. |
| 35 | Over current happen at DC/DC circuit detected by hardware | Restart the unit, if the error happens again, please return to repair center. |
| 36 | Over current happen at LLC circuit | Restart the unit, if the error happens again, please return to repair center. |
| 37 | LLC hardware fault | Restart the unit, if the error happens again, please return to repair center. |
| 40 | PV voltage is too high | Reduce the number of PV modules in series. |

| | | |
|----|---|--|
| 41 | Short circuited happen at PV port | Check if wiring is connected well. |
| 42 | PV power anomaly | Restart the unit, if the error happens again, please return to repair center. |
| 43 | Over current happen at PV port | Restart the unit, if the error happens again, please return to repair center. |
| 44 | PV current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 45 | PV1 high input power | Reduce the connected load. Restart the unit, if the error happens again, please return to repair center. |
| 46 | PV2 high input power | Reduce the connected load. Restart the unit, if the error happens again, please return to repair center. |
| 50 | Fan is locked | Check if wiring is connected well. Replace the fan. |
| 51 | Over temperature happen at PV circuit | The temperature of internal PV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 52 | Over temperature happen at INV circuit | The temperature of internal INV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 53 | Over temperature happen at Convert L circuit | The temperature of Convert L battery converter component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 54 | Over temperature happen at Convert H circuit | The temperature of internal Convert H component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 55 | Over temperature happen at LLC TX | The temperature of internal DC/DC TX is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 60 | CAN data loss | 1. Check if communication cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer. |
| 61 | Host data loss | |
| 62 | Synchronization data loss | |
| 63 | The firmware version of each inverter is not the same | 1. Update all inverter firmware to the same version. 2. Check the version of each inverter via LCD setting and make sure the CPU versions are same. If not, please contact your installer to provide the firmware to update. 3. After updating, if the problem still remains, please contact your installer. |
| 64 | The output current of each inverter is different | 1. Check if sharing cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer. |
| 65 | AC output mode setting is different | 1. Switch off the inverter and check LCD setting program 20. 2. For parallel system in single phase, make sure no 3P1, 3P2 or 3P3 is set on program 20. For supporting three-phase system, make sure no "PAL" is set on program 20. 3. If the problem remains, please contact your installer. |

| | | |
|----|---|---|
| 66 | Single unit is installed to parallel system | 1. Please check if single unit is installed to parallel system. 2. If this error happens during parallel installation, please check wires connection. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer. |
| 92 | DSP failed to communicate with MCU | Restart the unit, if the error happens again, please return to repair center. |